

# SERVICE MANUAL

P650HP6(-G) / P651HP6(-G)

*notebook*





**Notebook Computer**

**P650HP6(-G) / P651HP6(-G)**

**Service Manual**

## Notice

The company reserves the right to revise this publication or to change its contents without notice. Information contained herein is for reference only and does not constitute a commitment on the part of the manufacturer or any subsequent vendor. They assume no responsibility or liability for any errors or inaccuracies that may appear in this publication nor are they in anyway responsible for any loss or damage resulting from the use (or misuse) of this publication.

This publication and any accompanying software may not, in whole or in part, be reproduced, translated, transmitted or reduced to any machine readable form without prior consent from the vendor, manufacturer or creators of this publication, except for copies kept by the user for backup purposes.

Brand and product names mentioned in this publication may or may not be copyrights and/or registered trademarks of their respective companies. They are mentioned for identification purposes only and are not intended as an endorsement of that product or its manufacturer.

Version 1.0  
December 2016

## Trademarks

**Intel and Intel Core** are trademarks of Intel Corporation.

**Windows®** is a registered trademark of Microsoft Corporation.

Other brand and product names are trademarks and /or registered trademarks of their respective companies.





## About this Manual

This manual is intended for service personnel who have completed sufficient training to undertake the maintenance and inspection of personal computers.

It is organized to allow you to look up basic information for servicing and/or upgrading components of the ***P650HP6(-G) / P651HP6(-G)*** series notebook PC.

The following information is included:

Chapter 1, Introduction, provides general information about the location of system elements and their specifications.  
Chapter 2, Disassembly, provides step-by-step instructions for disassembling parts and subsystems and how to upgrade elements of the system.

Appendix A, Part Lists

Appendix B, Schematic Diagrams

Appendix C, Updating the FLASH ROM BIOS

## Preface

---

### IMPORTANT SAFETY INSTRUCTIONS

Follow basic safety precautions, including those listed below, to reduce the risk of fire, electric shock and injury to persons when using any electrical equipment:

1. Do not use this product near water, for example near a bath tub, wash bowl, kitchen sink or laundry tub, in a wet basement or near a swimming pool.
2. Avoid using a telephone (other than a cordless type) during an electrical storm. There may be a remote risk of electrical shock from lightning.
3. Do not use the telephone to report a gas leak in the vicinity of the leak.
4. Use only the power cord and batteries indicated in this manual. Do not dispose of batteries in a fire. They may explode. Check with local codes for possible special disposal instructions.
5. This product is intended to be supplied by a Listed Power Unit as follows:
  - AC Input of 100 - 240V, 50 - 60Hz, DC Output of 19V, 10.5A (**200 Watts**) minimum AC/DC Adapter.

### FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference.

This device must accept any interference received, including interference that may cause undesired operation.


## Instructions for Care and Operation

The notebook computer is quite rugged, but it can be damaged. To prevent this, follow these suggestions:


1. **Don't drop it, or expose it to shock.** If the computer falls, the case and the components could be damaged.



2. **Keep it dry, and don't overheat it.** Keep the computer and power supply away from any kind of heating element. This is an electrical appliance. If water or any other liquid gets into it, the computer could be badly damaged.




3. **Follow the proper working procedures for the computer.** Shut the computer down properly and don't forget to save your work. Remember to periodically save your data as data may be lost if the battery is depleted.



## Preface


4. **Avoid interference.** Keep the computer away from high capacity transformers, electric motors, and other strong magnetic fields. These can hinder proper performance and damage your data.
5. **Take care when using peripheral devices.**



## Power Safety

The computer has specific power requirements:

- Only use a power adapter approved for use with this computer.
- Your AC adapter may be designed for international travel but it still requires a steady, uninterrupted power supply. If you are unsure of your local power specifications, consult your service representative or local power company.
- The power adapter may have either a 2-prong or a 3-prong grounded plug. The third prong is an important safety feature; do not defeat its purpose. If you do not have access to a compatible outlet, have a qualified electrician install one.
- When you want to unplug the power cord, be sure to disconnect it by the plug head, not by its wire.
- Make sure the socket and any extension cord(s) you use can support the total current load of all the connected devices.
- Before cleaning the computer, make sure it is disconnected from any external power supplies.



### Power Safety Warning

Before you undertake any upgrade procedures, make sure that you have turned off the power, and disconnected all peripherals and cables (including telephone lines and power cord). It is advisable to also remove your battery in order to prevent accidentally turning the machine on.

## Battery Precautions

- Only use batteries designed for this computer. The wrong battery type may explode, leak or damage the computer.
- Do not continue to use a battery that has been dropped, or that appears damaged (e.g. bent or twisted) in any way. Even if the computer continues to work with a damaged battery in place, it may cause circuit damage, which may possibly result in fire.
- Recharge the batteries using the notebook's system. Incorrect recharging may make the battery explode.
- Do not try to repair a battery pack. Refer any battery pack repair or replacement to your service representative or qualified service personnel.
- Keep children away from, and promptly dispose of a damaged battery. Always dispose of batteries carefully. Batteries may explode or leak if exposed to fire, or improperly handled or discarded.
- Keep the battery away from metal appliances.
- Affix tape to the battery contacts before disposing of the battery.
- Do not touch the battery contacts with your hands or metal objects.

## Battery Guidelines

The following can also apply to any backup batteries you may have.

- If you do not use the battery for an extended period, then remove the battery from the computer for storage.
- Before removing the battery for storage charge it to 60% - 70%.
- Check stored batteries at least every 3 months and charge them to 60% - 70%.




### Battery Disposal

The product that you have purchased contains a rechargeable battery. The battery is recyclable. At the end of its useful life, under various state and local laws, it may be illegal to dispose of this battery into the municipal waste stream. Check with your local solid waste officials for details in your area for recycling options or proper disposal.

### Caution

Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Discard used battery according to the manufacturer's instructions.

### Battery Level

Click the battery icon  in the taskbar to see the current battery level and charge status. A battery that drops below a level of 10% will not allow the computer to boot up. Make sure that any battery that drops below 10% is recharged within one week.

## Related Documents


You may also need to consult the following manual for additional information:

### User's Manual on CD/DVD

This describes the notebook PC's features and the procedures for operating the computer and its ROM-based setup program. It also describes the installation and operation of the utility programs provided with the notebook PC.

## System Startup

1. Remove all packing materials.
2. Place the computer on a stable surface.
3. Insert the battery and make sure it is locked in position.
4. Securely attach any peripherals you want to use with the computer (e.g. keyboard and mouse) to their ports.
5. Attach the AC/DC adapter to the DC-In jack at the rear of the computer, then plug the AC power cord into an outlet, and connect the AC power cord to the AC/DC adapter.
6. Use one hand to raise the lid/LCD to a comfortable viewing angle (do not exceed 135 degrees); use the other hand (as illustrated in Figure 1) to support the base of the computer (**Note: Never** lift the computer by the lid/LCD).
7. Press the power button to turn the computer "on".




*Figure 1*  
**Opening the Lid/LCD/  
Computer with AC/DC  
Adapter Plugged-In**




### Shut Down

Note that you should always shut your computer down by choosing the **Shut down** command in **Windows** (see below). This will help prevent hard disk or system problems.

Click the icon  in the **Start Screen** and choose **Shut down** from the menu.



**Or**

Right-click the **Start button**  at the bottom of the **Start Screen** or the **Desktop** and choose **Shut down or sign out** > **Shut down** from the context menu.

# Contents

## Introduction .....1-1

Overview .....	1-1
Specifications .....	1-2
External Locator - Top View with LCD Panel Open .....	1-4
External Locator - Front & Right Side Views .....	1-5
External Locator - Left Side & Rear View .....	1-6
External Locator - Bottom View .....	1-7
Mainboard Overview - Top (Key Parts) .....	1-8
Mainboard Overview - Bottom (Key Parts) .....	1-9
Mainboard Overview - Top (Connectors) .....	1-10
Mainboard Overview - Bottom (Connectors) .....	1-11

## Disassembly .....2-1

Overview .....	2-1
Maintenance Tools .....	2-2
Connections .....	2-2
Maintenance Precautions .....	2-3
Disassembly Steps .....	2-4
Removing the Keyboard .....	2-5
Removing the Battery .....	2-6
Removing the Hard Disk Drive .....	2-8
Removing the System Memory (RAM) .....	2-10
Removing and Installing the M.2 SSD Module .....	2-13
Removing the Wireless LAN Module .....	2-16
Wireless LAN, Combo, 3G & LTE Module Cables .....	2-17
Removing the 3G/4G Module .....	2-17

## Part Lists .....A-1

Part List Illustration Location .....	A-2
Top .....	A-3
Bottom .....	A-4

Main Board .....	A-5
HDD .....	A-6
LCD .....	A-7
LCD (Sharp) .....	A-8

## Schematic Diagrams.....B-1

System Block Diagram .....	B-2
Processor 1/7 .....	B-3
Processor 2/7 .....	B-4
Processor 3/7 .....	B-5
Processor 4/7 .....	B-6
Processor 5/7 .....	B-7
Processor 6/7 .....	B-8
Processor 7/7 .....	B-9
DDR CHA SO-DIMM_0 .....	B-10
DDR CHA SO-DIMM_1 .....	B-11
DDR CHB SO-DIMM_0 .....	B-12
DDR CHB SO-DIMM_1 .....	B-13
Panel, Inverter .....	B-14
Redriver .....	B-15
Mini DP Port E .....	B-16
Mini DP Port F .....	B-17
HDMI Connector .....	B-18
VGA PCI Express .....	B-19
VGA Frame Buffer Partition .....	B-20
Frame Buffer Partition A .....	B-21
Frame Buffer Partition B .....	B-22
Frame Buffer Partition A_B .....	B-23
GPU Frame Buffer Partition .....	B-24
Frame Buffer Partition C .....	B-25
Frame Buffer Partition C_D .....	B-26

## Preface

GPU Decoupling .....	B-27	1.0DX_VCCSTG/VCCSFR_OC/2.5V .....	B-59
GPU Decoupling 2 .....	B-28	1V8_RUN/AON, NV3V3 .....	B-60
Straps and XTAL .....	B-29	NVVDD Phase 1 & 2 .....	B-61
IFP I/O Interface .....	B-30	NVVDDS .....	B-62
Misc - GPIO, I2C and ROM .....	B-31	PEX_VDD .....	B-63
NVIDIA Power Sequence .....	B-32	FBVDDQ .....	B-64
GPU NVVDD, FBVDDQ .....	B-33	VCC_Core & VCCSA .....	B-65
GPU GND .....	B-34	VCore Output Stage .....	B-66
PCH 1/9 .....	B-35	VCCGT .....	B-67
PCH 2/9 .....	B-36	VCCGT Output Stage .....	B-68
PCH 3/9 .....	B-37	LAN RTL8411, Card Reader .....	B-69
PCH 4/9 .....	B-38	AR_TBT .....	B-70
PCH 5/9 .....	B-39	AR_Power .....	B-71
PCH 6/9 .....	B-40	TPS65982, Type C .....	B-72
PCH 7/9 .....	B-41	TPS65982, Type A .....	B-73
PCH 8/9 .....	B-42	USB, Type A .....	B-74
PCH 9/9 .....	B-43	Audio Board_3D AMP .....	B-75
KBC IT8587 .....	B-44	HDD Board .....	B-76
USB Charger .....	B-45	Power Board .....	B-77
USB .....	B-46	LED Board .....	B-78
M.2 WLAN+BT, PCIE4X SSD .....	B-47	Click Board .....	B-79
M.2 3G/LTE .....	B-48	Finger Sensor Board .....	B-80
Realtek ALC892 .....	B-49	Power Board .....	B-81
TPA2008D2 .....	B-50	LED Board .....	B-82
TPM, CCD, TP .....	B-51		
Fan, LID, KB LED .....	B-52	<b>Updating the FLASH ROM BIOS..... C-1</b>	
Connector .....	B-53	Download the BIOS .....	C-1
DDR 1.2V / 0.6VS .....	B-54	Unzip the downloaded files to a bootable CD/DVD or	
VDD3, VDD5 .....	B-55	USB Flash drive .....	C-1
5V, 5VS, 3.3V, 3.3VS, 3.3VA .....	B-56	Set the computer to boot from the external drive .....	C-1
Power 1.0V, VCCIO .....	B-57	Use the flash tools to update the BIOS .....	C-2
AC_In, Charger .....	B-58	Restart the computer (booting from the HDD) .....	C-2




# Chapter 1: Introduction

## Overview

This manual covers the information you need to service or upgrade the **P650HP6(-G) / P651HP6(-G)** series notebook computer. Information about operating the computer (e.g. getting started, and the *Setup* utility) is in the *User's Manual*. Information about drivers (e.g. VGA & audio) is also found in the *User's Manual*. The manual is shipped with the computer.

Operating systems (e.g. *Windows 10*, etc.) have their own manuals as do application softwares (e.g. word processing and database programs). If you have questions about those programs, you should consult those manuals.

The **P650HP6(-G) / P651HP6(-G)** series notebook is designed to be upgradeable. See [Disassembly on page 2 - 1](#) for a detailed description of the upgrade procedures for each specific component. Please take note of the warning and safety information indicated by the “” symbol.

The balance of this chapter reviews the computer's technical specifications and features.

## Introduction

# Specifications



### Latest Specification Information

The specifications listed here are correct at the time of sending them to the press. Certain items (particularly processor types/speeds) may be changed, delayed or updated due to the manufacturer's release schedule. Check with your service center for more details.



### CPU Speed & Computer in DC Mode

Note that when the computer is in DC mode (powered by the battery only) the CPU may not run at full speed. This is a design feature implemented in order to protect the battery.



### SO-DIMM Memory Types

All SO-DIMM memory modules installed in the system should be identical (the same size and brand) in order to prevent unexpected system behavior.

Do not mix SO-DIMM memory module sizes and brands otherwise unexpected system problems may occur.

## Processor Options

**i7-7820HK (2.70GHz), i7-7700HQ (2.60GHz)**

8MB Smart Cache, **14nm**, DDR4-2133MHz, TDP 45W

*Supports Intel® CPU over-clocking technology on i7-6820HK*

## Core Logic

Intel® HM175 Express Chipset

## LCD Options

15.6" (39.62cm), 16:9, QFHD (3840x2160)/FHD (1920x1080)

## BIOS

AMI BIOS (64Mb SPI Flash-ROM)

## Memory

Four 260 Pin SO-DIMM Sockets Supporting **DDR4 2400MHz** Memory

Memory Expandable from **8GB (minimum)** up to **64GB (maximum)**

*Supports XMP 2666MHz (XMP support depends on processor)*

## Security

Security (Kensington® Type) Lock Slot

BIOS Password

Intel PTT for Systems Without TPM Hardware

(**Factory Option**) TPM 2.0

(**Factory Option**) Fingerprint Reader Module

## Video Adapter Options

**Microsoft Hybrid Graphics Mode or Discrete Graphics Mode**

Supports up to 4 Active Displays

Supports NVIDIA Surround View via HDMI x 1 and MiniDP x2

## Intel Integrated GPU

**Intel® HD Graphics 630**

Dynamic Frequency

Intel Dynamic Video Memory Technology

Microsoft DirectX®12 Compatible

## NVIDIA® Discrete GPU

**NVIDIA® GeForce GTX 1060**

**6GB** GDDR5 Video RAM

Microsoft DirectX®12 Compatible

Supports GPU Overclocking

## Pointing Device

Built-in Touchpad (scrolling key functionality integrated)

## Keyboard

(**Factory Option**) **Full Color Illuminated** Full-size Winkey Keyboard (with numeric keypad)

Or

(**Factory Option**) Full-size **Illuminated White LED** Winkey Keyboard (with numeric keypad)

**Storage**

(**Factory Option**) Two **SATA** M.2 2280 SSDs supporting RAID level 0/1

Or

(**Factory Option**) One **PCIe Gen3 x4** M.2 2280 SSD

Two Changeable 2.5" (6cm) **SATA** (Serial) Hard Disk Drives (HDDs)/SSDs (**1st: 7.0mm (h) & 2nd: 7.0mm/9.5mm (h)**) supporting RAID Level 0/1

Or

One changeable 2.5" (6cm) **7.0mm/9.5mm (h) SATA** (Serial) Hard Disk Drive/Solid State Drive (SSD)

**Audio**

High Definition Audio Compliant Interface

S/PDIF Digital Output

Two Speakers

Sound Blaster Audio

ANSP™ 3D sound technology on headphone output

Built-In Array Microphone

**Note:** External 5.1CH Audio Output Supported by Line-Out, Microphone-In and Headphone & S/PDIF Out Combo Jacks

**Interface**

Two USB 3.1 Gen 2 Type C Ports

Three USB 3.0 (USB 3.1 Gen 1) Ports (Including one AC/DC Powered USB port)

Two Mini DisplayPorts (1.3)

One HDMI-Out Port

One 2-In-1 Audio Jack (Headphone & S/PDIF Optical Output Combo Jack)

One Microphone-In Jack

One Line-Out Jack

One RJ-45 LAN Jack

One DC-In Jack

**Communication**

Built-In Gigabit Ethernet LAN

2.0M FHD PC Camera Module

(**Factory Option**) M.2 3G/4G Module

**WLAN/ Bluetooth M.2 Modules:**

(**Factory Option**) Intel® Wireless-AC 8265 Wireless LAN (**802.11ac**) + Bluetooth **4.1**

(**Factory Option**) Intel® Wireless-AC 3168 Wireless LAN (**802.11ac**) + Bluetooth **4.0**

(**Factory Option**) Qualcomm® Atheros Killer™ Wireless-AC 1535 Wireless LAN (**802.11ac**) + Bluetooth **4.1**

(**Factory Option**) Qualcomm® Wireless LAN (**802.11ac/ad**) + Bluetooth **4.1**

**Card Reader**

Embedded Multi-In-1 Push-Push Card Reader

MMC (MultiMedia Card) / RS MMC

SD (Secure Digital) / Mini SD / SDHC/ SDXC

**M.2 Slots**

Slot 1 for **Combo WLAN and Bluetooth** Module

Slot 2 for **SATA** or **PCIe Gen3 x4 SSD**

Slot 3 for **SATA SSD**

(**Factory Option**) Slot 4 for **3G/4G** Module

**Note:** (**Factory Option**) **LTE** or **802.11ad** Antenna

**M.2 SSD Limitation**

When slot 3 has an M.2 SATA SSD installed, then slot 2 will not be available for M.2 PCIe SSDs.

**Features**

Supports NVIDIA G-SYNC Technology in dGPU Mode

(G-SYNC is only supported if you have a G-SYNC capable display and a GTX series video adapter)

Virtual Reality Ready

**Environmental Spec****Temperature**

Operating: 5°C - 35°C

Non-Operating: -20°C - 60°C

**Relative Humidity**

Operating: 20% - 80%

Non-Operating: 10% - 90%

**Power**

Embedded 4-Cell Polymer Battery Pack, 60WH

Full Range AC/DC Adapter

AC Input: 100 - 240V, 50 - 60Hz

DC Output: 19V, 10.5A (**200W**)

**Dimensions & Weight**

385mm (w) \* 271mm (d) \* 25.4mm (h)

2.6kg (Barebone with 60WH Battery)

## Introduction

Figure 1  
Top View

1. PC Camera
2. \*PC Camera LED  
*\*When the PC camera is in use, the LED will be illuminated.*
3. Built-In Array Microphone
4. LCD
5. Speakers
6. Power Button
7. Keyboard
8. Touchpad & Buttons
9. Fingerprint Reader (Optional)

## External Locator - Top View with LCD Panel Open



## External Locator - Front & Right Side Views

*Figure 2*  
**Front View**

1. LED Indicator

FRONT VIEW



*Figure 3*  
**Right Side View**

1. Headphone & S/PDIF Combo Jack
2. Microphone-In Jack
3. Line-Out Jack
4. USIM Card Reader (for 3G/4G USIM Cards)
5. Multi-in-1 Card Reader
6. USB 3.1 Ports
7. USB 3.0 Port
8. RJ-45 LAN Jack
9. Security Lock Slot

RIGHT SIDE VIEW



## Introduction

### External Locator - Left Side & Rear View

*Figure 4*  
**Left Side View**

1. Vent
2. HDMI-Out Port
3. Powered USB 3.0 Port
4. Mini DisplayPorts

LEFT SIDE VIEW



*Figure 5*  
**Rear View**

1. Vent
2. DC-In Jack
3. USB 3.0/3.1 Port

REAR VIEW



## External Locator - Bottom View

*Figure 6*  
**Bottom View**

1. Vent



### **Overheating**

To prevent your computer from overheating, make sure nothing blocks any vent while the computer is in use.




## Introduction

*Figure 7*  
**Mainboard Top  
Key Parts**


1. Memory Slots  
DDR4 SO-DIMM
2. KBC-ITE IT8587
3. CMOS Battery

## Mainboard Overview - Top (Key Parts)





## Mainboard Overview - Bottom (Key Parts)



*Figure 8*  
**Mainboard Bottom  
Key Parts**


1. Mini-Card Connector (WLAN Module)
2. Mini-Card Connector (M.2 3G/SATA Module)
3. Mini-Card Connector (M.2 PCIE/SATA SSD Module)
4. GPU-GTX1060M
5. Memory Slots (DDR4 SO-DIMM)
6. CPU

## Introduction

*Figure 9*  
**Mainboard Top  
Connectors**

1. HDMI Port
2. USB Port 3.0  
Connector
3. Mini Display Port
4. USB Port 3.1  
Connector
5. DC-In Jack
6. Keyboard Cable  
Connector
7. TP Connector
8. Speaker  
Connector
9. USIM Card  
Reader (for 3G/  
4G USIM Cards)
10. Multi-in-1 Card  
Reader
11. RJ-45 LAN Jack

## Mainboard Overview - Top (Connectors)






## Mainboard Overview - Bottom (Connectors)

*Figure 10*  
**Mainboard Bottom  
Connectors**

1. HDD Connector
2. Battery Connector
3. Fan Connector
4. LCD Cable Connector
5. CCD Connector






# Chapter 2: Disassembly



## Overview

This chapter provides step-by-step instructions for disassembling the *P650HP6(-G)* / *P651HP6(-G)* series notebook's parts and subsystems. When it comes to reassembly, reverse the procedures (unless otherwise indicated).


We suggest you completely review any procedure before you take the computer apart.

Procedures such as upgrading/replacing the RAM, optical device and hard disk are included in the User's Manual but are repeated here for your convenience.

To make the disassembly process easier each section may have a box in the page margin. Information contained under the figure # will give a synopsis of the sequence of procedures involved in the disassembly procedure. A box with a  lists the relevant parts you will have after the disassembly process is complete. **Note:** The parts listed will be for the disassembly procedure listed ONLY, and not any previous disassembly step(s) required. Refer to the part list for the previous disassembly procedure. The amount of screws you should be left with will be listed here also.

A box with a  will also provide any possible helpful information. A box with a  contains warnings.

An example of these types of boxes are shown in the sidebar.



## Disassembly

---

**NOTE:** All disassembly procedures assume that the system is turned **OFF**, and disconnected from any power supply (the battery is removed too).

### Maintenance Tools

The following tools are recommended when working on the notebook PC:

- M3 Philips-head screwdriver
- M2.5 Philips-head screwdriver (magnetized)
- M2 Philips-head screwdriver
- Small flat-head screwdriver
- Pair of needle-nose pliers
- Anti-static wrist-strap

### Connections

Connections within the computer are one of four types:

Locking collar sockets for ribbon connectors	To release these connectors, use a small flat-head screwdriver to gently pry the locking collar away from its base. When replacing the connection, make sure the connector is oriented in the same way. The pin1 side is usually not indicated.
Pressure sockets for multi-wire connectors	To release this connector type, grasp it at its head and gently rock it from side to side as you pull it out. Do not pull on the wires themselves. When replacing the connection, do not try to force it. The socket only fits one way.
Pressure sockets for ribbon connectors	To release these connectors, use a small pair of needle-nose pliers to gently lift the connector away from its socket. When replacing the connection, make sure the connector is oriented in the same way. The pin1 side is usually not indicated.
Board-to-board or multi-pin sockets	To separate the boards, gently rock them from side to side as you pull them apart. If the connection is very tight, use a small flat-head screwdriver - use just enough force to start.

## Maintenance Precautions

The following precautions are a reminder. To avoid personal injury or damage to the computer while performing a removal and/or replacement job, take the following precautions:

1. **Don't drop it.** Perform your repairs and/or upgrades on a stable surface. If the computer falls, the case and other components could be damaged.
2. **Don't overheat it.** Note the proximity of any heating elements. Keep the computer out of direct sunlight.
3. **Avoid interference.** Note the proximity of any high capacity transformers, electric motors, and other strong magnetic fields. These can hinder proper performance and damage components and/or data. You should also monitor the position of magnetized tools (i.e. screwdrivers).
4. **Keep it dry.** This is an electrical appliance. If water or any other liquid gets into it, the computer could be badly damaged.
5. **Be careful with power.** Avoid accidental shocks, discharges or explosions.
  - Before removing or servicing any part from the computer, turn the computer off and detach any power supplies.
  - When you want to unplug the power cord or any cable/wire, be sure to disconnect it by the plug head. Do not pull on the wire.
6. **Peripherals** – Turn off and detach any peripherals.
7. **Beware of static discharge.** ICs, such as the CPU and main support chips, are vulnerable to static electricity. Before handling any part in the computer, discharge any static electricity inside the computer. When handling a printed circuit board, do not use gloves or other materials which allow static electricity buildup. We suggest that you use an anti-static wrist strap instead.
8. **Beware of corrosion.** As you perform your job, avoid touching any connector leads. Even the cleanest hands produce oils which can attract corrosive elements.
9. **Keep your work environment clean.** Tobacco smoke, dust or other air-born particulate matter is often attracted to charged surfaces, reducing performance.
10. **Keep track of the components.** When removing or replacing any part, be careful not to leave small parts, such as screws, loose inside the computer.

## Cleaning

Do not apply cleaner directly to the computer, use a soft clean cloth.

Do not use volatile (petroleum distillates) or abrasive cleaners on any part of the computer.



### Power Safety Warning

Before you undertake any upgrade procedures, make sure that you have turned off the power, and disconnected all peripherals and cables (including telephone lines and power cord). It is advisable to also remove your battery in order to prevent accidentally turning the machine on.

## Disassembly Steps

The following table lists the disassembly steps, and on which page to find the related information. **PLEASE PERFORM THE DISASSEMBLY STEPS IN THE ORDER INDICATED.**

### To remove the Keyboard:

1. Remove the keyboard *page 2 - 5*

### To remove the Battery:

1. Remove the battery *page 2 - 6*

### To remove the HDD:

1. Remove the battery *page 2 - 6*
2. Remove the HDD *page 2 - 8*

### To remove the System Memory:

1. Remove the battery *page 2 - 6*
2. Remove the system memory *page 2 - 10*

### To remove and install the M.2 SSD:

1. Remove the battery *page 2 - 6*
2. Remove the M.2 SSD *page 2 - 13*
3. Install the M.2 SSD *page 2 - 15*

### To remove the Wireless LAN Module:

1. Remove the battery *page 2 - 6*
2. Remove the WLAN *page 2 - 16*




### To remove the 3G/4G Module:

1. Remove the battery *page 2 - 6*
2. Remove the 3G/4G *page 2 - 18*



## Removing the Keyboard

1. Turn **off** the computer, turn it over.
2. Remove screws **1** - **2** from the bottom of the computer.
3. Open it up with the LCD on a flat surface before pressing at point **3** to release the keyboard module (use the special eject stick **4** to do this) while releasing the keyboard in the direction of the arrow **5** as shown (**Figure 1a**).
4. Carefully lift the keyboard **6** up, being careful not to bend the keyboard ribbon cable **7**. Disconnect the keyboard ribbon cable **7** from the locking collar socket by using a flat-head screwdriver to pry the locking collar pins **8** away from the base (**Figure 1b**).
5. Carefully lift the keyboard **6** off the computer (**Figure 1c**).



*Figure 1*  
**Keyboard Removal**

- Remove the screws from the bottom of the computer and then eject the keyboard using a special eject stick to push the keyboard out while releasing the keyboard as shown.
- Lift the keyboard up and disconnect the keyboard ribbon cable from the locking collar socket.
- Remove the keyboard.



### Re-inserting the Keyboard

When re-inserting the keyboard firstly, align the keyboard tabs at the bottom of the keyboard with the slots in the case.



- Eject Stick
- Keyboard

- 2 Screws


## Disassembly

*Figure 2*  
**Battery Removal**

- a. Remove the SD card cover and screws.
- b. Remove the bottom case.
- c. Locate the battery.

## Removing the Battery


1. Turn the computer **off**, and turn it over.
2. Remove the SD card cover **1** and screws **2** - **15** (*Figure 2a*).
3. Carefully lift the bottom case **16** up in the direction of the arrow **17** and remove it (*Figure 2b*).
4. The battery will be visible at point **18** on the computer (*Figure 2c*).



1. SD Card Cover  
16. Bottom Case

- 14 Screws

5. Carefully disconnect the cable **19**, then remove screws **20** - **22** (*Figure 3b*).
6. Lift the battery **23** off the computer (*Figure 3e*).
7. Reinsert the bottom case starting from point **24** as shown (*Figure 3f*) to avoid damaging the rear USB 3.0 port. Tighten the screws to secure the bottom case in place.



*Figure 3*  
**Battery Removal**  
(cont'd.)

- d. Disconnect the cable and remove the screws.
- e. Lift the battery off the computer.
- f. Reinsert the bottom case and tighten the screws.



23. Battery

- 3 Screws

## Disassembly

*Figure 4*  
**HDD Assembly  
Removal**


- Locate the HDD.
- Remove the screws.

## Removing the Hard Disk Drive

The hard disk drive can be taken out to accommodate other 2.5" serial (SATA) hard disk drives with a height of 9.5mm or 7mm (h). Follow your operating system's installation instructions, and install all necessary drivers and utilities (as outlined in **Chapter 4 of the User's Manual**) when setting up a new hard disk.

### Hard Disk Disassembly Process

- Turn **off** the computer, and remove the battery ([page 2 - 6](#)).
- The HDD will be visible at point **1** on the mainboard ([Figure 4a](#)).
- Remove screws **2** - **5** from the HDD assembly ([Figure 4b](#)).



6. Hard Disk

- 4 Screws



#### HDD System Warning

New HDD's are blank. Before you begin make sure:




You have backed up any data you want to keep from your old HDD.

You have all the CD-ROMs and FDDs required to install your operating system and programs.

If you have access to the internet, download the latest application and hardware driver updates for the operating system you plan to install. Copy these to a removable medium.



4. Slightly lift and pull the hard disk in the direction of arrow 6 (Figure 5c).
5. Lift the hard disk assembly 7 out of the bay 8 (Figure 5d).
6. Remove screws 9 - 16 and bracket 17 from the hard disk 18 (Figure 5e).
7. Reverse the process to install a new hard disk (do not forget to replace the screws).



### Installing 9.5mm or 7mm HDD

Note that the hard disks pictured on the following pages are all 7mm(h) hard disk drive.

In some cases 9.5mm(h) hard disk drives will be installed. It can be installed on either upper or lower slot.

There are two hard disk drive options:

**Two** changeable 2.5" (6cm) **7.0mm** (h) **SATA** (Serial) Hard Disk Drives/Solid State Drives (SSD) supporting RAID level 0/1

Or

**One** changeable 2.5" (6cm) **9.5mm** (h) **SATA** (Serial) Hard Disk Drive/Solid State Drive (SSD)

For more information, contact your distributor/supplier, and bear in mind your warranty terms.

Figure 5  
HDD Assembly  
Removal (cont'd.)

- c. Slightly lift and pull the HDD in the direction of the arrow.
- d. Lift the HDD assembly out of the bay.
- e. Remove the screws and bracket from the HDD.

7. HDD Assembly  
17. Adhesive Cover  
18. HDD

- 8 Screws

## Disassembly

*Figure 6*  
**RAM-1 Module Removal**


- The RAM modules will be visible at point ①.
- Remove the screws and lift the shielding plate out.

## Removing the System Memory (RAM)

The computer has four memory sockets for 260 pin Small Outline Dual In-line Memory Modules (SO-DIMM) supporting DDR4 Up to 2400 MHz. The main memory can be expanded up to 64GB. The total memory size is automatically detected by the POST routine once you turn on your computer.

### Memory-1 Upgrade Process

- Turn **off** the computer, turn it over, remove the keyboard ([page 2 - 5](#)).
- The RAM modules will be visible at point ① after removing the shielding plate ([Figure 6a](#)).
- Remove screws ② - ⑤ and lift the shielding plate ⑥ off the computer ([Figure 6b](#)).



#### Contact Warning

Be careful not to touch the metal pins on the module's connecting edge. Even the cleanest hands have oils which can attract particles, and degrade the module's performance.





#### 6. RAM Shielding Plate

- 4 Screws

4. Gently pull the two release latches (7 & 8) on the sides of the memory socket in the direction indicated by the arrows (**Figure 7c**). The RAM module 9 will pop-up (**Figure 7d**), and you can then remove it.
5. Pull the latches to release the second module if necessary.
6. Insert a new module holding it at about a 30° angle and fit the connectors firmly into the memory slot.
7. The module will only fit one way as defined by its pin alignment. Make sure the module is seated as far into the slot as it will go. DO NOT FORCE IT; it should fit without much pressure.
8. Press the module in and down towards the mainboard until the slot levers click into place to secure the module.

*Figure 7*  
**RAM-1 Module Removal (cont'd)**

- c. Pull the release latches.
- d. Remove the module.



### Contact Warning

Be careful not to touch the metal pins on the module's connecting edge. Even the cleanest hands have oils which can attract particles, and degrade the module's performance.



9. RAM Module

## Disassembly

*Figure 8*  
**RAM-2 Module Removal**

- The RAM modules will be visible at point **1** on the mainboard.
- Pull the release latches.
- Remove the module.



### Contact Warning


Be careful not to touch the metal pins on the module's connecting edge. Even the cleanest hands have oils which can attract particles, and degrade the module's performance.



4. RAM Module

## Memory-2 Upgrade Process

- Turn **off** the computer, turn it over, remove the battery ([page 2 - 6](#)).
- The RAM-2 modules will be visible at point **1** on the mainboard ([Figure 8a](#)).
- Gently pull the two release latches (**2** & **3**) on the sides of the memory socket in the direction indicated by the arrows ([Figure 8b](#)). The RAM module **4** will pop-up ([Figure 8c](#)), and you can then remove it.
- Pull the latches to release the second module if necessary.
- Insert a new module holding it at about a 30° angle and fit the connectors firmly into the memory slot.
- The module will only fit one way as defined by its pin alignment. Make sure the module is seated as far into the slot as it will go. **DO NOT FORCE IT**; it should fit without much pressure.
- Press the module in and down towards the mainboard until the slot levers click into place to secure the module.
- Replace the bottom cover and the screws (see [page 2 - 6](#)).
- Restart the computer to allow the BIOS to register the new memory configuration as it starts up.






# Removing and Installing the M.2 SSD Module


## M.2 SSD-1 Removal Procedure

1. Turn **off** the computer, turn it over, remove the battery ([page 2 - 6](#)).
2. The M.2 SSD module will be visible at point **1** on the mainboard ([Figure 9a](#)).
3. Remove the screw **2** ([Figure 9b](#)).
4. The M.2 SSD module **3** ([Figure 9c](#)) will pop-up, and you can remove it from the computer.
5. Reverse the process to install a new module (do not forget to replace the screws and thermal pad).

*Figure 9*  
**M.2 SSD-1 Module Removal**

- a. Locate the M.2 SSD.
- b. Remove the screw.
- c. The M.2 SSD module will pop up.



  
3.M2 SSD Module

- 1 Screw

## Disassembly

Figure 10

### M.2 SSD-2 Module Removal

- Locate the module.
- Disconnect the cables and remove the screw.
- The module will pop-up.
- Lift the module up off the socket.

### M.2 SSD-2 Removal Procedure

- Turn off the computer, remove the battery ([page 2 - 6](#)).
- Locate the module, it is visible at point **1** ([Figure 10a](#)).
- Remove the screw **2** from the module ([Figure 10b](#)).
- The module **3** will pop-up ([Figure 10c](#)).
- Lift the module **3** up and off the computer ([Figure 10d](#)).

a.




b.



c.



d.




3. M.2 SSD Module

- 1 Screw

## M.2 SSD Installation Procedure

1. Place the thermal pad **1** on the module as shown (**Figure 11a**).
2. Insert the module **2** in the computer (**Figure 11b**).
3. Tighten the screw **3** to secure it in place (**Figure 11c**).



### Thermal Pad

Be sure to place the thermal pad's adhesive side down onto the module surface as shown.



1. Thermal Pad
2. M2 SSD Module

- 1 Screw

*Figure 11*  
**M.2 SSD Module Installation**

- a. Place the thermal pad.
- b. Insert the module.
- c. Tighten the screw.

## Disassembly


*Figure 12*  
**Wireless LAN  
Module Removal**

- a. Locate the WLAN.
- b. Disconnect the cables **2** & **3**, and remove the screw **4**.
- c. The WLAN module will pop up.

Note: Make sure you reconnect the antenna cable to the “1 + 2” socket (*Figure 12b*).

## Removing the Wireless LAN Module

1. Turn **off** the computer, turn it over, remove the battery (*page 2 - 6*).
2. The Wireless LAN module will be visible at point **1** on the mainboard (*Figure 12a*).
3. Carefully disconnect the cables **2** & **3**, and then remove the screw **4** (*Figure 12b*).
4. The Wireless LAN module **5** (*Figure 12c*) will pop-up, and you can remove it from the computer.



5. Wireless LAN Module

- 1 Screw



## Wireless LAN, Combo, 3G & LTE Module Cables

Note that the cables for connecting to the antennae on WLAN, WLAN & Bluetooth Combo, 3G and LTE modules are not labelled. The cables/covers (each cable will have either a black or transparent cable cover) are color coded for identification as outlined in the table below.

Module Type	Antenna Type	Cable Color	Cable Cover Type
WLAN/WLAN & Bluetooth Combo	WM 1	Black	Transparent
	WM 2		White
LTE Broadband	LTE 1	Black	Black
	LTE 2		Blue
3G Broadband	3G 1	Black	Black
	3G 2		Blue

Cable 1 is usually connected to antenna 1 (Main) on the module, and cable 2 to antenna 2 (Aux).

## Removing the 3G/4G Module



## Disassembly

*Figure 13*  
**3G/4G Module Removal**

- Locate the module.
- Disconnect the cables and remove the screw.
- The module will pop-up.
- Lift the module up off the socket.

**3G/4G Module Removal Procedure**

- Turn off the computer, remove the battery ([page 2 - 6](#)).
- Locate the module, it is visible at point **1** ([Figure 13a](#)).
- Carefully disconnect the cables **2** & **3**, and then remove the screw **4** from the module ([Figure 13b](#)).
- The module **5** will pop-up ([Figure 13c](#)).
- Lift the module **5** up and off the computer ([Figure 13d](#)).



5. 3G/4G Module

- 1 Screw

---

# Appendix A:Part Lists

This appendix breaks down the *P650HP6(-G) / P651HP6(-G)* series notebook's construction into a series of illustrations. The component part numbers are indicated in the tables opposite the drawings.

**Note:** This section indicates the *manufacturer's* part numbers. Your organization may use a different system, so be sure to cross-check any relevant documentation.

**Note:** Some assemblies may have parts in common (especially screws). However, the part lists DO NOT indicate the total number of duplicated parts used.

**Note:** Be sure to check any update notices. The parts shown in these illustrations are appropriate for the system at the time of publication. Over the product life, some parts may be improved or re-configured, resulting in *new* part numbers.



---


## Part List Illustration Location

The following table indicates where to find the appropriate part list illustration.

*Table A - 1*  
**Part List Illustration  
Location**

Part	
Top	<i>page A - 3</i>
Bottom	<i>page A - 4</i>
Main Board	<i>page A - 5</i>
HDD	<i>page A - 6</i>
LCD	<i>page A - 7</i>
LCD (Sharp)	<i>page A - 8</i>

Top




ITEM	PART NAME	PART NO	REMARK
1	WHITE R. 10 USA MP-CHENKACAP PS50E BLACK SPRING ISOLATION WITH VARIO KEY + V/O FRAME	6-80-P65S0-011-1	
1	WHITE R. 10 USA MP-CHENKACAP PS50E BLACK SPRING ISOLATION WITH VARIO KEY + V/O FRAME	6-80-P6500-013-1	
2	TOP CASE MODULE (DNKYDKKAPDK) P650RP6	6-39-P65P2-013-N	
2	TOP CASE MODULE (DNKYDKKAPDK) P651RP6	6-39-P65P2-113-N	
3	HINGE COVER L (TELJUN TNG715BX-OM262BX) P650SE	6-42-P6502-0L2	
4	SCREW M2*4L KI NI ICT NY (DD=04.5,DT=0.4)	6-35-B1120-4RE	
5	SPEAKER FRONT RAL 5049 15.2 2W 40 DB/220H L-29K3MM P-230MM PS50E	6-23-5P650-0S1	
6	SCREW M2*6.2L NI ICT NY FOR SPEAKER	6-35-Z1120-6R2	
7	SCREW M2*2L KI NI ICT NY (DD=05 ,T=0.5)	6-35-B1120-2R0	
8	DDR BRACKET(SUS304) P650RS	6-33-P65S2-012	
9	SPK BRK-3 (SECC T=1.0MM) P650SE	6-33-P6502-031	
10	FFC CABLE LED TO MB (P=0.5) 1845MM 60V 4PIN PS50E	6-43-P6500-040	
11	LED BOARD V3.0 P650RP6	6-77-P65P4-D03	
12	FFC CABLE FINGER TO MB (P=1.0) 1235MM 60V 4PIN PS50E	6-43-P6500-051	ONLY FOR W/FINGER
13	TOUCH PAD SYNAPTICS TM-03163-002 P650RS (108*65MM)	6-49-P65S3-010	
14	HINGE COVER R MODULE P650SE	6-42-P6502-R00	
15	TP MYLAR PET P650RP6	6-40-P65P2-023	
16	POWER BOARD V1.0 P650RP6	6-77-P65PC-D01	
17	FFC CABLE POWER TO MB (P=1.0) 925MM 60V 4PIN PS50E	6-43-P6500-030	
18	AUDIO 3DHP BOARD V2.0 P650RP6	6-77-P65P8-D12	
19	SCREW M2.5*4L KI NI ICT NY	6-35-21125-4R0	
20	WIRE CABLE 30PIN 50V FOR 3D AMP AUDIO 85MM (P670RP6)	6-43-P67P6-010	
21	SCREW M2*2L KI BK/Z ICT NY(08,T=0.6)	6-35-B6120-2RE	
22	FUNCTION KEY FOR CLICK BUTTON MODULE W/O FINGER PS50R6	6-23-KP65R-022	
22	FUNCTION KEY FOR CLICK BUTTON MODULE W/FINGER PS50R6	6-23-KP65R-012	
23	SCREW M2*3L KI BZ ICT NY (DD=04.5,DT=0.4)	6-35-B6120-3RD	
24	CLICK W/O FP MYLAR PET (48*14*0.5T) P650SE	6-40-P6502-080	ONLY FOR W/O FINGER
25	CLICK W/FINGER MYLAR2 PET (48*14*0.3T) P650SE	6-40-P6502-040	ONLY FOR W/FINGER
26	FFC CABLE TRANSFER TO MB (P=0.5) 1945MM 60V 6PIN PS50R6	6-43-P65R0-011	
27	FFC CABLE TP TO CLICK (P=0.5) 1105MM 60V 8PIN PS50R6	6-43-P65R0-021	
28	CLICK BOARD V1.0 (W/O FP) P650RP6	6-77-P65P2-D01-1	
28	CLICK BOARD V1.0+FINGER BOARD V1.0 P650RP6	6-77-P65PA-N01	
29	TAPE MYLAR TRANSPARENT (20*10*0.05) P1803HM	6-40-P1803-020	

Figure A - 1  
Top


Bottom

Figure A - 2  
Bottom



ITEM	PART NAME	PART NO	REMARK
1	BOTTOM CASE MODULE P650RP6	6-39-P65P3-014	
1	BOTTOM CASE MODULE P651RP6	6-39-P65P3-114	
2	SCREW M2.5*6L K BZ ICT NY	6-35-82125-6RA	
3	PRODUCT LABEL FOR P650RP6 (FOLLOW NEW CE SAFETY)	6-45-P650RP63-011	
3	PRODUCT LABEL FOR P650RP6 (FOLLOW NEW CE SAFETY)	6-45-P651RP63-011	
3	PRODUCT LABEL FOR P650RP6-G (FOLLOW NEW CE SAFETY)	6-45-P650RP6G-011	
3	PRODUCT LABEL FOR P650RP6-G (FOLLOW NEW CE SAFETY)	6-45-P651RP6G-011	
3	PRODUCT LABEL (ST PRO-PI) FOR P651RP6-H	6-45-P651RP6H-010	
3	PRODUCT LABEL FOR P651HP6	6-45-P651HP63-010	
3	PRODUCT LABEL FOR P650HP6	6-45-P650HP63-010	
3	PRODUCT LABEL FOR P650HP6-G	6-45-P650HP6G-010	
3	PRODUCT LABEL FOR P651HP6-G	6-45-P651HP6G-010	
3	PRODUCT LABEL FOR P650HP3	6-45-P650HP33-010	
3	PRODUCT LABEL FOR P651HP3	6-45-P651HP33-010	
3	PRODUCT LABEL FOR P650HP3-G	6-45-P650HP3G-010	
3	PRODUCT LABEL FOR P651HP3-G	6-45-P651HP3G-010	



## Main Board

[illegible]

*Figure A - 3*  
**Main Board**


HDD

Figure A - 4  
HDD



ITEM	PART	NAME	PART	NO	REMARK
1	SCREW	M3*2.5L KI NI ICT NY	6-35-B1130-2R5		
2	2 IN 1 HDD BRACKET MODULE	P650SE	6-33-P650J-100		

LCD



ITEM	PART NAME	PART NO	REMARK
1	LCD PROTECT MYLAR BOPP N650DU	6-40-N6508-040	
2	CCD LENS PMMA P650SE	6-42-P6501-010	
3	LCD FRONT COVER MODULE P650SE	6-39-P6501-015	
4	SCREW M2*2.5L KI BK/Z ICT NY 1# #0.5 T=0.5	6-35-B6120-2RD	
5	LED 156" UHD IPS/CEP SMORG LENS/LITE-IN ' SUPPORT 5W 6-SMC 'LED 28M	6-50-L1226-M03	
5	LED 156" FHD/IPS/CEP LG LP56W6-SP1 40 LED SUPPORT 5W 6-SMC ' 32M	6-50-LB232-L04	
5	LED 156" FHD/IPS/CEP LG LP56W6-SP1 (M4) (M4) LED 32M	6-50-LB232-L06	
5	LCD 156" UHD (IPS/CEP) LG LP56U01-SP1 (LED) 28M	6-50-L1226-L00	
5	LED 156" FHD/IPS/CEP LG LP56W6-SP1 (M4) (LED) 32M	6-50-LB232-L08	
5	LED 156" FHD/IPS/CEP LG LP56W6-SP1 (M4) (LED) 32M	6-50-LB232-L07	
6	WIRE CALBE FOR CCD 535MM 30V 8PIN (CM) P650SE	6-43-P650T-011-1	
7	ANTENNA PEKX W/LAN W/L 2 PCB 2.4G/5G CABLE BLACK L-800MM P650SE	6-23-7P650-072	必須先接XG/LITE-1天線 才可以接LITE-2天線
8	LCD BACK COVER MODULE P650SE	6-39-P6501-027	
8	LCD BACK COVER MODULE P651SE	6-39-P6511-026	
9	ANTENNA PEKX W/LAN W/L 2 PCB 2.4G/5G CABLE BLACK L-800MM P650SE	6-23-7P650-052	
10	WIRE CABLE FOR EXPAND/RED 20MM 30V 3P (C) CM/FIL COM/LAMP/PS/RS	6-43-P6501-032-1C	
10	WIRE CABLE FOR EXPAND/RED 20MM 30V 3P (C) CM/FIL COM/LAMP/PS/RS	6-43-P6501-042-1C	
10	WIRE CABLE FOR EXPAND 30MM (C) 30V 3P (C) CM/FIL COM/LAMP/PS/RS	6-43-P65S1-010-1S	
11	WIRE CABLE FOR EXPAND/RED 20MM 30V 3P (C) CM/FIL COM/LAMP/PS/RS	6-88-W65DC-5100	OPTION
11	WIRE CABLE FOR EXPAND/RED 20MM 30V 3P (C) CM/FIL COM/LAMP/PS/RS	6-88-P775C-4900	OPTION
12	ANTENNA PEKX W/LAN W/L 2 PCB 2.4G/5G L-500MM P650SE	6-23-7P650-060	需要出XG/LITE 模組 必須先接XG/LITE-1天線
13	ANTENNA PEKX W/LAN W/L 2 PCB 2.4G/5G L-500MM P650SE	6-23-7P650-041	
14	FRONT COVER GLUE UAD ONTTO 5000 (80X40.15) FOR W65SSZ	6-40-W6551-020	
15	SCREW M2*2L KI BK/Z ICT NY (#0.8,T=0.6)	6-35-B6120-2RE	
16	LCD HINGE L (SK7) P650RS	6-33-P65S1-0L1	
17	LCD HINGE R (SK7) P650RP6	6-33-P65P1-0R1	
18	SCREW M2.5*4L KI NI ICT NY	6-35-21125-4R0	
19	ANTENNA PEKX W/LAN W/L 2 PCB 2.4G/5G CABLE BLACK L-800MM P650SE	6-88-P872F-8100	FOR 6-88-P872F-8100
20	802.11AD TAPE MYLAR/BLACK/20X15#0.12/P655SRP6	6-40-P655S-P10	FOR 6-88-P872F-8100
21	802.11AD CABLE 64MM POLAR/BLACK/WHITE KURATA CONNECTOR P870M2	6-23-7P872F-010	FOR 6-88-P872F-8100
22	802.11AD COPPER FOIL P775DM2	6-47-P7751-211	FOR 6-88-P872F-8100

Figure A - 5  
LCD

## A.Part Lists

This exploded view diagram illustrates the assembly of the LED display. The components are labeled as follows:

- 1: LED display panel
- 2: Mounting bracket
- 3: Mounting bracket
- 4: Mounting bracket
- 5: Mounting bracket
- 6: Mounting bracket
- 7: Mounting bracket
- 8: Mounting bracket
- 9: Mounting bracket
- 10: Mounting bracket
- 11: Mounting bracket
- 12: Mounting bracket
- 13: Mounting bracket
- 14: Mounting bracket
- 15: Mounting bracket
- 16: Mounting bracket
- 17: Mounting bracket
- 18: Mounting bracket
- 19: Mounting bracket
- 20: Mounting bracket
- 21: Mounting bracket
- 22: Mounting bracket
- 23: Mounting bracket

ITEM	PART	NAME	PART NO	REMARK
1	LCD PROTECT MYLAR BOPP	N650DU	6-40-N6508-040	
2	CCD LENS PMMA	P650SE	6-42-P6501-010	
3	LCD FRONT COVER MODULE	P650SE	6-39-P6501-015	
4	SCREW M2*2.5L KI BK-Z	ICT NY 1# #35 T=0.5	6-35-B6120-2RD	
5	LCD 066 9410 CPT IPS MODE SHARP L066010404 LED 310MM F/T UPDATE		6-50-L1231-A01	
6	WIRE CALBE FDR CDD 535MM 30V 8PIN CMO	P650SE	6-43-P650T-011-1	
7	ANTENNA PEEX SATE JN LTE-F20 KU/KA/6G/5G/4G/LTE/3G/2G/1G/100M/F/T/UPDATE		6-23-7P650-072	必須先換30LITE-F20/天線 才可以換 LTE-2天線
8	LCD BACK COVER MODULE	P650SE	6-39-P6501-027	
9	LCD BACK COVER MODULE	P651SE	6-39-P6511-026	
10	ANTENNA PEEX WLAN JEN W2 PCB 24G/5G BLACK L-500MM	P650SE	6-23-7P650-052	
11	WIRE CAVAIL CABLE FOR EXPOHART 270MM 30V 4P 0.07WAL COMBIBEDS P650SE		6-43-P6501-052-1C	
11	ONE CAMERA DESIGN FOR DISCRETEDESIGN 28 PIN D0600 W550C FOCUS WHITE-LED W200MM		6-88-W65DC-5100	OPTION
11	ONE CAMERA DESIGN FOR DISCRETEDESIGN 28 PIN D0600 W550C FOCUS WHITE-LED W200MM		6-88-P775C-4900	OPTION
12	ANTENNA PEEX SATE JN LTE-F20 KU/KA/6G/5G/4G/LTE/3G/2G/1G/100M/F/T/UPDATE		6-23-7P650-060	需要換30LITE 模組 必須先換30LITE-F20
13	ANTENNA PEEX WLAN JEN W1 PCB 24G/5G L-500MM	P650SE	6-23-7P650-041	OPTION
14	FRONT COVER GLASS URO ONITTO 5000 180*40*1.5 FDR W6553S		6-40-W6551-020	
15	SCREW M2*2L KI BK-Z	ICT NY(#8,T=0.6)	6-35-B6120-2RE	
16	LCD HINGE L (SK7)	P650RS	6-33-P65S1-0L1	
17	LCD HINGE R (SK7)	P650RP6	6-33-P65P1-0R1	
18	SCREW M2.5*4L KI NI	ICT NY	6-35-21125-4R0	
19	ANTENNA PEEX WLAN JEN W2 PCB 24G/5G BLACK L-500MM	P650SE	6-88-P8722-8100	FDR 6-88-P872F-8100
20	LCD PANEL BRACKET (SECC) P650SE		6-33-P6501-010	
21	802.11AD TAPE MYLARBLACKX20W15*40.127P65SRP6		6-40-P655S-P10	FDR 6-88-P872F-8100
22	802.11AD CABLE 64MM BLACK4000E M0000A CONNECTER P7002M2		6-23-P7872-010	FDR 6-88-P872F-8100
23	802.11AD COPPER FOLIO P775SD2M2		6-47-P7751-211	FDR 6-88-P872F-8100



# Appendix B: Schematic Diagrams

This appendix has circuit diagrams of the *P650HP6(-G) / P651HP6(-G)* notebook's PCB's. The following table indicates where to find the appropriate schematic diagram.

Diagram - Page	Diagram - Page	Diagram - Page	Diagram - Page
System Block Diagram - Page B - 2	Frame Buffer Partition A_B - Page B - 23	KBC IT8587 - Page B - 44	VCC_Core & VCCSA - Page B - 65
Processor 1/7 - Page B - 3	GPU Frame Buffer Partition - Page B - 24	USB Charger - Page B - 45	VCore Output Stage - Page B - 66
Processor 2/7 - Page B - 4	Frame Buffer Partition C - Page B - 25	USB - Page B - 46	VCCGT - Page B - 67
Processor 3/7 - Page B - 5	Frame Buffer Partition C_D - Page B - 26	M.2 WLAN+BT, PCIE4X SSD - Page B - 47	VCCGT Output Stage - Page B - 68
Processor 4/7 - Page B - 6	GPU Decoupling - Page B - 27	M.2 3G/LTE - Page B - 48	LAN RTL8411, Card Reader - Page B - 69
Processor 5/7 - Page B - 7	GPU Decoupling 2 - Page B - 28	Realtek ALC892 - Page B - 49	AR_TBT - Page B - 70
Processor 6/7 - Page B - 8	Straps and XTAL - Page B - 29	TPA2008D2 - Page B - 50	AR_Power - Page B - 71
Processor 7/7 - Page B - 9	IFP I/O Interface - Page B - 30	TPM, CCD, TP - Page B - 51	TPS65982, Type C - Page B - 72
DDR CHA SO-DIMM_0 - Page B - 10	Misc - GPIO, I2C and ROM - Page B - 31	Fan, LID, KB LED - Page B - 52	TPS65982, Type A - Page B - 73
DDR CHA SO-DIMM_1 - Page B - 11	NVIDIA Power Sequence - Page B - 32	Connector - Page B - 53	USB, Type A - Page B - 74
DDR CHB SO-DIMM_0 - Page B - 12	GPU NVVDD, FBVDDQ - Page B - 33	DDR 1.2V / 0.6VS - Page B - 54	Audio Board_3D AMP - Page B - 75
DDR CHB SO-DIMM_1 - Page B - 13	GPU GND - Page B - 34	VDD3, VDD5 - Page B - 55	HDD Board - Page B - 76
Panel, Inverter - Page B - 14	PCH 1/9 - Page B - 35	5V, 5VS, 3.3V, 3.3VS, 3.3VA - Page B - 56	Power Board - Page B - 77
Redriver - Page B - 15	PCH 2/9 - Page B - 36	Power 1.0V, VCCIO - Page B - 57	LED Board - Page B - 78
Mini DP Port E - Page B - 16	PCH 3/9 - Page B - 37	AC_In, Charger - Page B - 58	Click Board - Page B - 79
Mini DP Port F - Page B - 17	PCH 4/9 - Page B - 38	1.0DX_VCCSTG/VCCSFR_OC/2.5V - Page B - 59	Finger Sensor Board - Page B - 80
HDMI Connector - Page B - 18	PCH 5/9 - Page B - 39	1V8_RUN/AON, NV3V3 - Page B - 60	Power Board - Page B - 81
VGA PCI Express - Page B - 19	PCH 6/9 - Page B - 40	NVVDD Phase 1 & 2 - Page B - 61	LED Board - Page B - 82
VGA Frame Buffer Partition - Page B - 20	PCH 7/9 - Page B - 41	NVVDDS - Page B - 62	
Frame Buffer Partition A - Page B - 21	PCH 8/9 - Page B - 42	PEX_VDD - Page B - 63	
Frame Buffer Partition B - Page B - 22	PCH 9/9 - Page B - 43	FBVDDQ - Page B - 64	

Table B - 1  
**SCHEMATIC  
DIAGRAMS**




## Version Note


The schematic diagrams in this chapter are based upon version 6-7P-P65P9-002. If your mainboard (or other boards) are a later version, please check with the Service Center for updated diagrams (if required).

# System Block Diagram

Sheet 1 of 81  
System Block  
Diagram




## Processor 1/7

Sheet 2 of 81  
Processor 1/7


## Schematic Diagrams

# Processor 2/7

Sheet 3 of 81  
Processor 2/7




**Processor 3/7 B - 5**




## Processor 4/7

Sheet 5 of 81  
Processor 4/7



**Processor 5/7 B - 7**






## Processor 6/7

## B. Schematic Diagrams


Sheet 7 of 81  
Processor 6/






## DDR CHA SO-DIMM\_0

Sheet 9 of 81  
DDR CHA SO-  
DIMM 0




## DDR CHA SO-DIMM\_1




Sheet 10 of 81  
DDR CHA SO-DIMM\_1

## DDR CHB SO-DIMM\_0

Sheet 11 of 81  
DDR CHB SO-  
DIMM 0




## DDR CHB SO-DIMM\_1






## Panel, Inverter

**Sheet 13 of 81**  
**Panel, Inverter**




## Redriver



## Mini DP Port E

**Sheet 15 of 81**  
**Mini DP Port E**




### Mini DP Port F B - 17



## B - 18 HDMI Connector


## VGA PCI Express B - 19





## VGA Frame Buffer Partition

Sheet 19 of 81  
VGA Frame Buffer  
Partition







## Schematic Diagrams

## Frame Buffer Partition B

Sheet 21 of 81  
Frame Buffer  
Partition B




## Frame Buffer Partition A\_B



Sheet 22 of 81  
Frame Buffer  
Partition A\_B

## GPU Frame Buffer Partition

Sheet 23 of 81  
GPU Frame Buffer  
Partition




Sheet 24 of 81  
Frame Buffer  
Partition C






Frame Buffer Partition C\_D




## GPU Decoupling


Sheet 26 of 81  
GPU Decoupling

# GPU Decoupling 2

Sheet 27 of 81  
GPU Decoupling 2




## Straps and XTAL B - 29




## IFP I/O Interface

**Sheet 29 of 81**  
**IFP I/O Interface**




# Misc - GPIO, I2C and ROM





## B.Schematic Diagrams

Sheet 31 of 81  
NVIDIA Power  
Sequence






\_\_\_\_\_

# GPU GND




**PCH 1/9 B - 35**




**PCH 2/9**

## B.Schematic Diagrams



**PCH 3/9 B - 37**







Schematic Diagrams

PCH 4/9


Sheet 37 of 81  
PCH 4/9



## PCH 5/9


Sheet 38 of 81  
PCH 5/9

PCH 6/9



Sheet 39 of 81  
PCH 6/9

B.Schematic Diagrams




\_\_\_\_\_

# PCH 8/9




**PCH 9/9**




**KBC IT8587**

Sheet 43 of 81  
KBC IT8587






### USB Charger B - 45




# USB

**Sheet 45 of 81**  
**USB**




## M.2 WLAN+BT, PCIE4X SSD



Sheet 46 of 81  
M.2 WLAN+BT,  
PCIE4X SSD

## M.2 3G/LTE

**Sheet 47 of 81**  
**M.2 3G/LTE**



## B.Schematic Diagrams

**Layout Note:**  
U43 pin 1 - pin 11 and pin 47 and pin 48 are Digital signals.  
The others are Analog signals.

**Layout Note:**  
(1)MIC1-L (U13.23) (2)MIC1-R (U13.22) (3)LINE-L (U13.23) (4)LINE-R (U13.24)  
周圍必須包圍 AUDIO, 且儘量避免跨越 +5V2 & +V12V plane.

**PCB Layout Details:**


- Digital Section:** Includes MIC1, MIC2, and LINE inputs. Components like U13, U14, and U15 are shown. Signals include MIC1\_CLK, MIC1\_DATA, MIC2\_CLK, MIC2\_DATA, and LINE\_L, LINE\_R.
- Analog Section:** Includes ALC889, ALC888, and ALC887. Signals include MIC1-L, MIC1-R, MIC2-L, MIC2-R, and LINE\_L, LINE\_R. Components like U13, U14, and U15 are shown.
- Power and Grounding:** 3.3VS\_AUD, 3.3VS\_VDD, 3.3VS\_VDD2, 3.3VS\_VDD3, 3.3VS\_VDD4, 3.3VS\_VDD5, 3.3VS\_VDD6, 3.3VS\_VDD7, 3.3VS\_VDD8, 3.3VS\_VDD9, 3.3VS\_VDD10, 3.3VS\_VDD11, 3.3VS\_VDD12, 3.3VS\_VDD13, 3.3VS\_VDD14, 3.3VS\_VDD15, 3.3VS\_VDD16, 3.3VS\_VDD17, 3.3VS\_VDD18, 3.3VS\_VDD19, 3.3VS\_VDD20, 3.3VS\_VDD21, 3.3VS\_VDD22, 3.3VS\_VDD23, 3.3VS\_VDD24, 3.3VS\_VDD25, 3.3VS\_VDD26, 3.3VS\_VDD27, 3.3VS\_VDD28, 3.3VS\_VDD29, 3.3VS\_VDD30, 3.3VS\_VDD31, 3.3VS\_VDD32, 3.3VS\_VDD33, 3.3VS\_VDD34, 3.3VS\_VDD35, 3.3VS\_VDD36, 3.3VS\_VDD37, 3.3VS\_VDD38, 3.3VS\_VDD39, 3.3VS\_VDD40, 3.3VS\_VDD41, 3.3VS\_VDD42, 3.3VS\_VDD43, 3.3VS\_VDD44, 3.3VS\_VDD45, 3.3VS\_VDD46, 3.3VS\_VDD47, 3.3VS\_VDD48, 3.3VS\_VDD49, 3.3VS\_VDD50, 3.3VS\_VDD51, 3.3VS\_VDD52, 3.3VS\_VDD53, 3.3VS\_VDD54, 3.3VS\_VDD55, 3.3VS\_VDD56, 3.3VS\_VDD57, 3.3VS\_VDD58, 3.3VS\_VDD59, 3.3VS\_VDD60, 3.3VS\_VDD61, 3.3VS\_VDD62, 3.3VS\_VDD63, 3.3VS\_VDD64, 3.3VS\_VDD65, 3.3VS\_VDD66, 3.3VS\_VDD67, 3.3VS\_VDD68, 3.3VS\_VDD69, 3.3VS\_VDD70, 3.3VS\_VDD71, 3.3VS\_VDD72, 3.3VS\_VDD73, 3.3VS\_VDD74, 3.3VS\_VDD75, 3.3VS\_VDD76, 3.3VS\_VDD77, 3.3VS\_VDD78, 3.3VS\_VDD79, 3.3VS\_VDD80, 3.3VS\_VDD81, 3.3VS\_VDD82, 3.3VS\_VDD83, 3.3VS\_VDD84, 3.3VS\_VDD85, 3.3VS\_VDD86, 3.3VS\_VDD87, 3.3VS\_VDD88, 3.3VS\_VDD89, 3.3VS\_VDD90, 3.3VS\_VDD91, 3.3VS\_VDD92, 3.3VS\_VDD93, 3.3VS\_VDD94, 3.3VS\_VDD95, 3.3VS\_VDD96, 3.3VS\_VDD97, 3.3VS\_VDD98, 3.3VS\_VDD99, 3.3VS\_VDD100.

## B.Schematic Diagrams


## TPA2008D2

Sheet 49 of 81  
TPA2008D2

## B. Schematic Diagrams




## TPM, CCD, TP B - 51





## Fan, LID, KB LED

Sheet 51 of 81  
Fan, LID, KB LED



### LED BOARD

LED BOARD

3.3VS

C477

0.01uF 16V\_XTR\_04

J\_LED1

X\_NC2

X\_NC1

LED\_HDD#

3.3VS

GND

FP225H-012810M

PCB Footprint = fp225-012g

LED ACIN [43]

LED PWK [43]

LED BAT\_CHG [43]

LED BAT\_FULL [43]

LED NUMB [43]

LED CAPN [43]

LED\_SCROLL [43]

ARRPLAN\_LED# [43]

R817 0.04

PS8331\_SW [31,30,38]

R816 0.04

DGPU\_PWR\_EN [31,38,43,59]

請EC PIN24送出存SSD  
LED動作的指示，透過AP通知BIOS 在告知BC 做出動作

LED\_HDD# 4

U34 74HC1G08GW

EC\_SSD\_LED# [43]

PCH\_SATAHDD\_LED# [36]

### FP

FP

3.3VS

J\_FP1

NCK

USB\_PN7 [35]

USB\_PP7 [35]

30mOhm

L32

30mOhm

FCM1005KF-121120

FP225H-004S10M

PCB Footprint = JXT\_FP225H-004XXAM

6-20-94AA0-004

### POWER BTN BOARD CONN

POWER BTN BOARD CONN

3.3VS

J\_BTN1

M\_BTN# [55]

J\_BTN1

FP225H-004S10M

PCB Footprint = JXT\_FP225H-004XXAM

6-20-94AA0-004

### HDD BOARD (P655x不上件)

HDD BOARD (P655x不上件)

5V

J\_SATA2

SATA\_TXP3 [36]

SATA\_TXN3 [36]

SATA\_RXN3 [36]

SATA\_RXP3 [36]

P670RG-M\_TPLED [43]

5V

C755

10uF 6.3V\_XSR\_06

50185-0304101

PCB Footprint = 50185-0304X

6-21-121420-215

### Audio Connect

Audio Connect

5V

J\_AUDIO2

J\_AUDIO1

J\_AUDIO0

88107-30001

5V\_PWR

3VS\_PWR

3.3VS

3.3V

L46

L47

HCB1005KF-121120

HCB1005KF-121120

HCB1005KF-121120

OVVS

HEADPHONE\_R

HEADPHONE\_L

EC\_AUDIO\_DET\_R

AMP\_EN

SMB\_CLK

SMB\_DATA

HP\_JSGND\_EN

OVIN

R351

6-21-41A00-215

AUDIO2

搭配3D AMP小板上此件(J\_AUDIO2)

from EC [43]

EC\_AUDIO\_DET# [43]

from PCH [34]

PCH\_HP\_PLUG [34]

R339 0.04

R342 0.04

EC\_AUDIO\_DET\_R

AMP\_EN [49]

SMB\_CLK [37,38,53]

SMB\_DATA [37,50,53]

[3,9,10,11,12,13,14,15,17,30,31,34,36,37,38,39,40,42,43,46,47,48,49,50,51,55,59,60,62,70]

[17,45,48,53,55,58,59,62,63,64,65,66,67,71,73]

[13,17,36,48,49,50,51,55,60,61]

[5,30,34,37,40,42,43,46,49,51,54,55,56,57,58,59,60,61,62,63,68]

[13,43,49,53,54,55,56,57,62,64,65,66,67]

3.3V


5V

VDD3


VIN

## DDR 1.2V / 0.6VS

Sheet 53 of 81  
DDR 1.2V / 0.6VS




## VDD3, VDD5


Sheet 54 of 81  
VDD3, VDD5

**5V, 5VS, 3.3V, 3.3VS, 3.3VA**

## B. Schematic Diagrams




## Power 1.0V, VCCIO B - 57



Schematic Diagrams


AC\_In, Charger

Sheet 57 of 81  
AC\_In, Charger






# 1.0DX\_VCCSTG/VCCSFR\_OC/2.5V




Sheet 58 of 81  
1.0DX\_VCCSTG/  
VCCSFR\_OC/2.5V

## B.Schematic Diagrams

Sheet 59 of 81  
1V8\_RUN/AON,  
NV3V3




## NVVDD Phase 1 &amp; 2



Sheet 60 of 81  
NVVDD Phase 1 & 2

# NVVDDS

**Sheet 61 of 81**  
**NVVDDS**




[illegible]

**FBVDDQ**


PAGE22: FBVDDQ, and MXM Mounting Holes

## FBVDDQ PHASE 1 and 2

FBVDDQ FOR N17\_VGA




## B.Schematic Diagrams






\_\_\_\_\_

## VCore Output Stage



## Schematic Diagrams

# VCCGT




Sheet 66 of 81  
VCCGT

## B.Schematic Diagrams

## VCCGT Output Stage

## B. Schematic Diagrams

Sheet 67 of 81  
VCCGT Output  
Stage




Sheet 68 of 81  
LAN RTL8411, Card  
Reader




**AR\_TBT**

## B. Schematic Diagrams



## Schematic Diagrams

## AR\_Power




## B.Schematic Diagrams

Sheet 70 of 81  
AR\_Power


## Schematic Diagrams

## TPS65982, Type C

Sheet 71 of 81  
TPS65982, Type C



**S65982, Type A B - 73**






Schematic Diagrams

USB, Type A

Sheet 73 of 81  
USB, Type A




## Audio Board\_3D AMP B - 75


Schematic Diagrams

HDD Board

Sheet 75 of 81  
HDD Board




## Power Board

Sheet 76 of 81  
Power Board

## Schematic Diagrams


## LED Board

Sheet 77 of 81  
LED Board




# Click Board


Sheet 78 of 81  
Click Board



Finger Sensor Board



# Power Board




Sheet 80 of 81  
Power Board



Schematic Diagrams

LED Board

Sheet 81 of 81  
LED Board



# Appendix C: Updating the FLASH ROM BIOS

## To update the FLASH ROM BIOS, you must:

- Download the BIOS update from the web site.
- Unzip the files onto a bootable CD/DVD/USB Flash Drive.
- Reboot your computer from an external CD/DVD/USB Flash Drive.
- Use the flash tools to update the flash BIOS using the commands indicated below.
- Restart the computer booting from the HDD and press **F2** at startup enter the BIOS.
- Load setup defaults from the BIOS and save the default settings and exit the BIOS to restart the computer.
- After rebooting the computer you may restart the computer again and make any required changes to the default BIOS settings.

## Download the BIOS

1. Go to [www.clevo.com.tw](http://www.clevo.com.tw) and point to **E-Services** and click **E-Channel**.
2. Use your user ID and password to access the appropriate download area (BIOS), and download the latest BIOS files (the BIOS file will be contained in a batch file that may be run directly once unzipped) for your computer model (see sidebar for important information on BIOS versions).

## Unzip the downloaded files to a bootable CD/DVD or USB Flash drive

1. Insert a bootable CD/DVD/USB flash drive into the CD/DVD drive/USB port of the computer containing the downloaded files.
2. Use a tool such as Winzip or Winrar to unzip all the BIOS files and refresh tools to your bootable CD/DVD/USB flash drive (you may need to create a bootable CD/DVD with the files using a 3rd party software).

## Set the computer to boot from the external drive

1. With the bootable CD/DVD/USB flash drive containing the BIOS files in your CD/DVD drive/USB port, restart the computer and press **F2** (in most cases) to enter the BIOS.
2. Use the arrow keys to highlight the **Boot** menu.
3. Use the “+” and “-” keys to move boot devices up and down the priority order.
4. Make sure that the CD/DVD drive/USB flash drive is set first in the boot priority of the BIOS.
5. Press **F4** to save any changes you have made and exit the BIOS to restart the computer.



### BIOS Version

Make sure you download the latest correct version of the BIOS appropriate for the computer model you are working on.

**You should only download BIOS versions that are V1.0X.XX or higher as appropriate for your computer model.**

Note that BIOS versions are not backward compatible and therefore **you may not downgrade your BIOS to an older version** after upgrading to a later version (e.g if you upgrade a BIOS to ver 1.0X.05, you **MAY NOT** then go back and flash the BIOS to ver 1.0X.04).

## BIOS Update

---

### Use the flash tools to update the BIOS

1. Make sure you are not loading any memory management programs such as HIMEM by holding the **F8** key as you see the message “**EFI Shell**”. You will then be prompted to give “**Y**” or “**N**” responses to the programs being loaded by EFI Shell. Choose “**N**” for any memory management programs.
2. You should now see **DISK fsX:\>** (X is the designated drive number for the CD/DVD drive/USB flash drive).
3. **Type the following command:**

**fsX:\> Flash.nsh**

4. The utility will then proceed to flash the BIOS.
5. You should then be prompted to press any key to restart the system or turn the power off, and then on again but make sure you remove the CD/DVD/USB flash drive from the CD/DVD drive/USB port before the computer restarts.

### Restart the computer (booting from the HDD)

1. With the CD/DVD/USB flash drive removed from the CD/DVD drive/USB port the computer should restart from the HDD.
2. Press **F2** as the computer restarts to enter the BIOS.
3. Use the arrow keys to highlight the **Exit** menu.
4. Select **Load Setup Defaults** (or press **F3**) and select “**Yes**” to confirm the selection.
5. Press **F4** to save any changes you have made and exit the BIOS to restart the computer.

### Your computer is now running normally with the updated BIOS

You may now enter the BIOS and make any changes you require to the default settings.